

इरिसेट नेटवर्क प्रयोगशाला प्रयोग नं: एन डब्लू एल - 01

IRISET

NETWORK LABORATORY EXPERIMENT No: NWL - 01

नाम				
Name	:			
अनुक्रमांक		प्राप्त अंक		
Roll No	:	 Marks Awarded	:	
पाठ्यक्रम				
Course	:			
दिनांक		अनुदेशक का हस्ताक्षर		
Date	:	 Instructor Initial	:	

Name of Experiment: Establishing a LAN

Object

Establishing a LAN by connecting the Desktop PCs as per the topology diagram.

Introduction

Local Area Networks (LANs): are networks that connect computers and resources in a building or buildings close together. The computers share resources such as hard-drives, printers, data, applications etc...

TCP/IP: Network protocols help your computers speak the same language so they can share data. Network protocols define the rules for communication. The TCP/IP protocol is used just about everywhere. After the Internet boom, it became the standard protocol for networks.

IP Address and Subnet Mask: The most important setting is the IP address. The IP address gives each computer a unique address where it can be accessed in the network. An IP address is 32 bits long and represented as four OCTETS in dotted decimal notation. The IP address has four numbers between 0 and 255 that are separated by periods. All the computers are numbered in a series.

The subnet mask determines the network in which the computer is located. This is especially important in large networks that are divided into several subnets. In your small network, all the computers are in the same subnet.

MAC Address: It is a unique hardware identification number provided to a node (desktop PC) at layer2 level. It consists of 6 Bytes of Hexadecimal numbers separated by a colon. First 3 bytes identify OUI (Organizational unique Identifier) assigned by IEEE and rest 3 bytes for product serial numbers. MAC assists in addressing packets/ frames through unicast, broadcast or multicast. The MAC address is permanently burnt into the ROM.

Switch: is a layer 2 (Data link Layer) switching device, that connects LAN segments. The switch is an intelligent device, based on the MAC address; the switch transfers the packets/ frames to the destination.

NWL-01 Page 1 of 10


Apparatus Required

- 1. Desktop PC with NIC card
- 2. Patch card (straight cable, both ends terminated with RJ 45 connectors)
- 3. Switch

Procedure

- 1. Study the topology diagram & use the network cable / Patch chord from NIC card of your Desktop PC to a free port on a switch
- 2. Assign IP address to your Desktop PC after choosing the protocols (TCP/IP) required.
- 3. Connect two or more Desktop PCs on the switch ports
- 4. Test the connectivity with OS commands

Topology Diagram




NWL-01 Page 2 of 10

The topology diagram shows the WINDOWS (**Windows Vista**) Desktop PCs, which are to be configured with IP address.

Assigning IP address

- 1. Click Start,
- 2. Point to Settings,
- 3. Click Control Panel, and then
- 4. Double-click the Network & Sharing Center icon

Network sharing center window appears on the screen




Click on view status link

Local area Connection Status dialog box opens

Click on properties

User Account Control dialog box opens

Then give user account control permission by clicking on **Continue**



Network and

Sharing

Center

NWL-01 Page 3 of 10

Select Internet protocol version4 (TCP/IPV4)
& click on properties

Internet Protocol Version4 (TCP/IP4) properties dialog box opens

- 1. Click on, use the following IP address
- 2. Then type the IP address
- e.g. Use 192.168.1.2 for the first computer
 Use 192.168.1.3 on the second computer
 Use 192.168.1.4 for the third computer and so on.
- 3. Subnet mask stays the same for all the computers


Type subnet mask as 255.255.255.0.


4. Default gateway

{Default gateway is required to connect your network with other network}

[Here no need of mentioning gateway as we are not connecting our network with any other Network]

- 5. DNS server addresses {DNS server address is required to convert URL address into IP address} [Here no need of converting IP address into URL]
- 6. Click on OK





NWL-01 Page 4 of 10

Setting the Computer Names and Workgroups


You must assign a unique name & workgroup to each and every Desktop PC / node. Like the IP address, the name of each and every Desktop PC / node in a workgroup should also be unique.

To assign your computers a name and a workgroup, follow these steps:

- 1. Click Start, point to Settings, and then click Control Panel.
- 2. Double-click the System icon.



System window (as shown below) opens



Click on Change Settings icon for changing the computer name and workgroup


User Account Control dialog box opens

Then give user account control permission by clicking on Continue

NWL-01 Page 5 of 10

System Properties dialog box opens

Click on **Change** icon & further click on **OK**




Computer Name/Domain Changes window will opens

1. Assign each computer a meaningful name.

E.g. NWL-PC-1

- 2. The name will appear in the Network
- 3. Assign every computer the same workgroup e.g. IRISET
- You can type a description that specifies what this computer is used for or who works on it.
- 5. Click OK.
- 6. Restart your computer.



NWL-01 Page 6 of 10


Verification of Established LAN

Step 1: To Check the Network Card and driver software

1. Click on Start, Programs,
Accessories, Command Prompt

(Or)

Click on **Start**, **Run** and type **cmd** in the Run dialog box and click on **O.K**



- 2. A new "Command Prompt window" appears with DOS prompt like C: \>_
- 3. Type, "Ping 127.0.0.1" <Enter> to check the local configuration of TCP/IP i.e. A **local loop back** check, you will find the reply as shown below if TCP/IP configuration is OK
- 4. If you get a reply stating Reply from 127.0.0.1: bytes=32 time<10ms TTL=128

```
Reply from 127.0.0.1: bytes=32 time<10ms TTL=128

Ping statistics for 127.0.0.1:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

This test confirms that your network card and software drivers are installed correctly.

- 5. If you receive a message stating **Request Timed Out**, check that:
 - The network card is inserted properly in the PCI slot in the computer it may have become loose.
 - Try re-installing the network card drivers.
- 6. Repeat Step 1 again.
- 7. Now check response from your local system IP address
- e.g. **Ping** < **IP** address of your system> Record the observations

Ding statistics for	Packets			
Ping statistics for	Sent	Received	Lost	% loss

NWL-01 Page 7 of 10

8. Then Check the response from the other PCs connected on SWITCH using ping command with its respective IP address. ex. **Ping** <**IP** address of destination **PC**> Record the observations

Ding statistics for	Packets			
Ping statistics for	Sent	Received	Lost	% loss

- 9. If you receive a message stating Request Timed Out, the reason may be
 - The Destination PC may not be switched on

(OR)

- The cable connectivity (or) media cable from your PC to the Destination PC may be having break.
- 10. If you receive a message stating **Destination host un-reachable**, the reason may be
 - The other system may not be in the same network
- 11. On default ping will send 4 echo requests only. To increase no. of echo request C:/>Ping <neighbor PCs IP address> -n 50 (request to send 50 echo requests)
- 12. During the ping is in progress disconnect patch cable for a while and reconnect

Record the observations

<u> </u>	e cora uno obcentamente						
	Ding statistics for		Pack	cets			
	Ping statistics for	Sent	Received	Lost	% loss		

13. Try Ping <ip address> -t,

This will sends continuous echo requests to the specified host until stopped by pressing Ctrl-C

{This continuous echo requests will certainly help in tracing the failure}

Step 2: To Check the Desktop PC name, Ethernet (MAC Address) & IP Address

1. Click on Start, Programs, Accessories, Command Prompt

(Or)

- 2. Click on **Start**, **Run** and type **cmd** in the Run dialog box and click on **O.K**
- 3. In the Command Prompt window, type

C:/> ipconfig /all

NWL-01 Page 8 of 10

The Command prompt window will be open as shown below.

C:\Win	dows\system32\cmd.exe
Micro	right (c) 2006 Microsoft Corporation. All rights reserved.
C:\Us	ers\JOSHI>ipconfig /all
Windo	ows IP Configuration
No.	ost Name : DESKTOP-PC-1 rimary Dns Suffix : ode Type : Hybrid P Routing Enabled : No NS Proxy Enabled : No
Ether	net adapter Local Area Connection:
	onnection-specific DNS Suffix .: escription : Intel(R) 82566DM-2 Gigabit Network Connec
Ph Dh Au IF Su De	ysical Address : 00-1E-90-1D-12-D1 ICP Enabled : No Utoconfiguration Enabled : Yes IVA Address : 192.168.1.2(Preferred) Ubnet Mask : 255.255.255.0 If ault Gateway : Enabled

Observations: Record the observations in the tabular form

		Configured information
MAC address of the system		
IP address and subnet mask		
Default gateway configured		
Name of the computer		
Workgroup name		
DHCP Sever		
DNS Servers	1.	
	2.	

NWL-01 Page 9 of 10

Exercise

1.	What is PING, Why it is required?
2.	Why Subnet mask is required with IP address?
3.	Name the protocol used for establishing the LAN?
4.	What is the function of NIC card?

NWL-01 Page 10 of 10